

DSS-5000P

Battery Diagnostic Service System

For testing 6- and 12-volt automotive /
12-volt and 24-volt charging systems.




Users Guide

Contents

Chapter 1: Introduction	5	Chapter 9: Settings	24
Personal Precautions	5	WiFi	24
Symbols Conventions	5	WiFi Setup Procedure	24
Description	5	Adding A Network	24
Accessories	5	Deleting A Network	24
Tester Components	6	Printer Settings	25
Controller	6	Adding A WiFi Printer (Admin Only)	25
Tester Pod	6	Adding A Bluetooth Printer (Admin Only)	25
Charging Dock	6	Deleting A Printer (Admin Only)	25
Test Preparation	7	Email	25
Inspecting the Battery	7	Add Address (Admin Only)	25
Testing Out-of-Vehicle	7	Edit Address (Admin Only)	25
Testing In-Vehicle	7	Deleting An Address (Admin Only)	25
Connecting To A Battery	7	Server Settings	25
Setting User Preferences	7	User Settings (Admin Only)	26
Initial Power Up	7	User Management (Admin Only)	26
Main Menu	9	Language Settings	26
Viewing Additional Screens	9	System Language	26
Main Menu Icons	9	Test Result Language	26
Chapter 2: System Test	10	Email Language	26
Battery Test	10	Print Language	26
System Test	11	Display Settings	26
Test Results-Summary	11	Brightness	26
Battery Test Results	11	Auto Brightness	26
Chapter 3: Battery Test	14	Sleep Time	26
Chapter 4: Check In	16	Dim Time	26
Chapter 5: Customer Delivery	18	BMIS Login (Admin Only)	26
Chapter 6: Inventory	20	Shop Information (Admin Only)	27
Chapter 7: Messages	22	Shop Information	27
Accessing Messages	22	Test Settings	27
Message Types	22	Device List	28
Chapter 8: History	23	Add Tester Pod	28
Tool History	23	Deleting A Diagnostic Base	28
Totals By Test Decision	23	Add CVG Device	28
Totals By Test Type	23	Version Information	28
Totals By Date And Location	23	Factory Preset	28
Vehicle History	23	Legal Information	28
Vehicle Select Option	23	Check for Updates	28
User History	23	Chapter 10: Support	29
		User Manual	29
		Self-Diagnostics	29
		Appendix A: Battery Information Screen Descriptions	30
		Appendix B: Recommended Test Procedure	31
		VIN Scanning	31
		Scanning Tips	31

Chapter 1: Introduction

Personal Precautions




! DANGER	
	<p>Risk of explosive gases. Never smoke or allow a spark or flame in the vicinity of a battery.</p> <p>Batteries can produce a highly explosive mix of hydrogen gas and oxygen, even when the battery is not in operation. Always work in a well-ventilated area.</p>

! WARNING	
<p>Wash hands after handling.</p> <p>REQUIRED BY CALIFORNIA PROP. 65: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.</p>	

Inspect the battery for damage and check the electrolyte level. If the electrolyte level is too low, replenish it and fully charge the battery. Always use the necessary safety precautions when working with batteries to prevent severe injury or death. Follow all manufacturers' instructions and BCI (Battery Council International) safety recommendations, which include the following precautions:

- ⇒ Battery acid is highly corrosive. If acid enters your eyes, immediately flush them thoroughly with cold running water for at least 15 minutes and seek medical attention. If battery acid gets on your skin or clothing, wash immediately with a mixture of water and baking soda.
- ⇒ Always wear proper safety glasses or face shield when working with or around batteries.
- ⇒ Keep hair, hands, and clothing as well as the analyzer cords and cables away from moving engine parts.
- ⇒ Remove any jewelry or watches before you start servicing the battery.
- ⇒ Use caution when working with metallic tools to prevent sparks or short circuits.
- ⇒ Never lean over a battery when testing, charging, or jump starting.

Symbols Conventions

Symbol	Description
	The safety symbol indicates instructions for avoiding hazardous conditions and personal injury.
	The safety symbol with the words CAUTION , WARNING , or DANGER indicates instructions for avoiding hazardous conditions and personal injury.
	The wrench symbol indicates procedural notes and helpful information.

Description

The analyzer uses function-specific applications accessed through a series of menus and icons to guide users through the battery testing process for consistent testing implementation and accuracy. These are accessed using the Controller's touch screen display. Test results can be displayed on the full-color screen, printed, or wirelessly emailed.

Accessories




A033 Lead Post Adapters

Tester Components


Controller



- ① **Carrying Handle:** For carrying the Controller and Tester Pod (when attached).
- ② **Controller Release Lever:** Press to release the Controller from the Tester Pod.
- ③ **Power Button:** Hold for 2 seconds to turn the Controller on and off independent of the Tester Pod. Flashes when the Controller is being charged.
- ④ **Touch Screen:** Primary user interface.



- ⑤ **Camera & Flashlight:** For VIN scanning and identification.
- ⑥ **Temperature Sensor:** For measuring battery temperature.



- ⑦ **Micro-USB Port:** For updating and servicing the Controller when a WiFi network is not available.
- ⑧ **Power Supply Connection**

Tester Pod



- ① **Controller Charging Contacts:** For charging and communicating with the Controller when mounted to the Tester Pod.
- ② **Status Indicator LEDs:**
 - ⏻ - Power is on.
 - 📶 - Tester Pod is communicating with the Controller.
 - ⚡ - Clamps reversed
- ③ **Integrated Printer:** For printing and sharing test results.
- ④ **Clamp Storage Mounts:** Use to keep the test clamps protected when the tester is not in use.
- ⑤ **Tester Pod Internal Batteries**

Charging Dock



- ① **Tester Pod Charging Contacts:** For charging the Tester Pod
- ② **Power Supply Connection**



IMPORTANT: The DSS-5000 automatically checks and installs any software updates every night. Always leave the Controller/Tester Pod in the Dock plugged into a 110v outlet and connected to a WiFi network every night.

Test Preparation

Inspecting the Battery

Before starting the test visually inspect the battery for:

- Cracked, buckled, or leaking case. If you see any of these defects, replace the battery.
- Corroded, loose, or damaged cables and connections. Repair or replace them as needed.
- Corrosion on the battery terminals, and dirt or acid on the case top. Clean the case and terminals using a wire brush and a mixture of water and baking soda.
- Low electrolyte level. If the electrolyte level is too low, add distilled water to fill up to ½ above the top of the plates and fully charge the battery. Do not overfill.
- Corroded or loose battery tray and hold-down fixture. Tighten or replace as needed.

Testing Out-of-Vehicle

The preferred battery test location is in the vehicle. However, if you plan to test out of the vehicle:

- Always disconnect the negative cable from the battery first and reconnect it last.
- Always use a carry tool or strap to lift and transport the battery.

 **WARNING**

Failure to properly install lead terminal adapters, or using adapters that are dirty or worn, may cause false test results.

When testing side-post or Group 31 batteries, always use lead terminal adapters provided with the tester—do not test at the battery’s steel bolts. To avoid damage, never use a wrench to tighten the adapters more than ¼ turn.

Testing In-Vehicle

The preferred test position is at the battery posts. If you must test at a remote-post location, it should have both a positive and negative post. Otherwise, you must remove the battery and perform an out-of-vehicle test.

At the start of the test, make sure all vehicle accessory loads are off, the key is not in the ignition, and the doors are closed.

Connecting To A Battery

 **CAUTION**

Do not connect the tester to a voltage source greater than 30 Vdc.

Connect the clamps to the tester: the red clamp to the positive (+) terminal and the black clamp to the negative (-) terminal.

If you connect the clamps in the wrong polarity (positive to negative or negative to positive), the tester displays CLAMPS REVERSED! Reconnect the clamps.

To make sure both sides of the clamps are gripping the terminals, rock the each clamp back and forth. A poor connection will prevent testing, and the tester will display the message CHECK CONNECTION. If the message reappears after you have correctly reconnected the clamps, clean the terminals and reconnect.

Setting User Preferences


Before starting your test you may want to customize the use of your analyzer by setting preferences in the Settings (⚙️) Menu. The Settings Menu is described in Chapter 9.

Initial Power Up

1. Upon initial power-up, the Language Settings screen is displayed. Tap **Next** to continue.

System Language	Select the Controller default language displayed on the screen.
Test Result Language	Select the Controller default language for all displayed tests and test results.
Email Language	Select the default standard language for the analyzer to use for all tests and results sent via email.
Print Language	Select the default standard language for the analyzer to use for all tests and results printed using a networked printer.

2. A Consent to collect data screen is displayed. Tap the Consent check box and then tap **Next** to continue.
3. Using the displayed keypad template, enter the new user name and password.
4. Tap **Next** to continue.

 **IMPORTANT:** By default, the first user created is assigned Administrator rights. Tap Add User to add additional users. See Chapter 9: Settings to change these defaults.

5. Select the correct manufacturer logo and tap **Next** to continue.

6. The Date/Time Settings are displayed. Tap **Next** to continue after making any adjustments.

Select Time Format:	12-hour or 24-hour format
Select Date Format:	DD/MM/YYYY, MM/DD/YYYY, or YYYY/MM/DD
Select Time Zone:	Time zone offset from Greenwich Mean Time
Set Date:	Set the current date
Set Time:	Set the current time in the selected time zone

7. The Test Settings are displayed. Tap **Next** to continue after making any adjustments.

Battery Rating	Default: CCA (Cold Cranking Amps)
Temperature Units	Select Fahrenheit or Celsius
Decimal Separator	Select decimal point or comma

8. A list of devices connected to the tester is displayed.

To add a device, tap the plus (+) sign and follow the on-screen instructions. To unlink from a device, tap the displayed serial number to select it. Tap the trash can icon (🗑️) to delete it.



NOTE: A passkey number is automatically generated once the Bluetooth pairing has been established.

9. A listing of detected Configured WiFi networks is displayed.

To select a network: For initial setup, no networks will be displayed here yet.

To add a network: Tap the plus (+) sign, then select from one of the displayed detected networks.

To manually add a network, tap the plus (+) sign again. Follow the on-screen instructions to select the Network SSID, Security, and IP Settings. Tap **Next** when finished.

Use the onscreen keypad to manually enter the Network SSID, security type, and IP settings. If necessary, enter the WiFi network password. Tap **Next** when finished.

A confirmation screen is displayed when the analyzer has successfully connected to the WiFi network.

To delete a network: Tap a displayed network to select it. Tap trash can icon (🗑️) to delete it.

10. The BMIS (Battery Management Information System) Account screen is displayed. Tap **Yes** to enter the username and the password or **No** to skip this step.

Country	Username	Password
U.S. Nissan	nissan@dss5000.com	nissan1
U.S. Infiniti	infiniti@dss5000.com	infiniti1
Nissan Canada	nissancanada@dss5000.com	nissan1
Infiniti Canada	infiniticanada@dss5000.com	infiniti1

11. A searchable list of dealerships is displayed. Enter the Dealer ID or dealership name to search for the correct dealership and tap ➔.

12. The Email Address Book screen (Admin Only) is displayed.

13. The Shop Information screen (Admin Only) is displayed

Use the onscreen keypad to enter the store name, address, and phone number. Tap **Next** to continue.


Store Name	<input type="text" value="Midtronics"/>
Street Address	<input type="text" value="7000 Monroe"/>
Street Address 2	<input type="text"/>
City	<input type="text" value="Willowbrook"/>
State	<input type="text" value="IL"/>
Zipcode	<input type="text" value="60527"/>
Phone #	<input type="text" value="1-630-323-2800"/>

14. The login screen is displayed.



Tap a user name to access the Main Menu.

Main Menu




1 Menu Bar

Log Out	Log out current user	93%	Controller internal battery level
	Bluetooth connectivity status		Controller internal battery status
	WiFi signal strength		Connected battery voltage


2 Main Menu Selection Area

Viewing Additional Screens

The dots at the bottom or side of a menu or results screen indicate additional screens are available. Use your finger to swipe horizontally left, right, up or down across the Controller screen to view all of the results.



Swipe Horizontally




Swipe Vertically

Main Menu Icons

Icon	Description
System Test	Tests the battery, starting and charging systems of a vehicle. The battery must be in the vehicle to perform this test.
Battery Test	Tests an in-vehicle battery using conductance and Conductance Profiling™ to diagnose the cranking capability and reserve capacity.
Check In	For testing batteries in incoming vehicles.
Customer Delivery	For testing batteries in vehicles prior to final customer delivery.
Inventory	For testing vehicle batteries in dealer inventory awaiting sale. Use as part of a comprehensive lot management program.
Messages	Displays alerts and notifications for upcoming tests and activities including scheduled tests, tool software updates and maintenance opportunities.
History	Access archived test histories or search test history by VIN or by technician.
Settings	Setup/adjust: WiFi, printer setup, email settings, user information, default language, display and sound settings, BMIS information, shop information, and connected devices. Also access to tester software version information.
Support	Access the analyzer Self-Test and a digitized version of the Instruction Manual.

Chapter 2: System Test



Use System Test to perform Battery Tests on in-vehicle batteries using test parameters determined by vehicle VIN or year, make, and model of the vehicle being tested. Following the Battery Test, the vehicle starting and charging systems are also tested.



NOTE: An In Vehicle Test test will always associate the in-vehicle battery with the VIN of the vehicle in which it is installed.


At any time during the test tap to return to the previous screen or to return to the Main Menu.

Battery Test

1. Connect the Tester Pod test clamps to the battery (**Black** to negative [-], **Red** to [+]).
2. Press the Controller Release Lever and disconnect the Controller from the Tester Pod.
3. On the Controller at the Main Menu tap **System Test**.
4. Tap **Next** at the Connect Clamps screen. The Acquire VIN screen is displayed.
5. Use the camera built into the back of the Controller handle to scan the VIN bar code. For best results, use the barcode located on the driver's side door frame. The VIN is also displayed behind the windshield on the driver's side dashboard.



NOTE: Refer to Appendix B for recommended scanning procedures and VIN scanning help.




Controller



Drivers Door Frame



Windshield



Manual Entry: Use the on-screen keypad to manually type the 17-digit VIN and tap **Next**.

1	2	3	4	5	6	7	8	9	0
W	E	R	T	Y	U	P			
A	S	D	F	G	H	J	K	L	
Z	X	C	V	B	N	M			
Back									Next


The displayed digit counter will count up the alphanumeric characters as they are being entered on the keypad.

6. If this is the first time the vehicle is being tested tap **Yes** if the installed battery is original equipment or **No** if a replacement battery has been installed.

If **No** is selected, enter the battery rating. Tap Reset to re-enter the battery rating

7. The Edit Battery Information screen displays vehicle and battery information based on the VIN.

If the displayed information is correct, tap **Next** to begin the Battery Test. Tap on the corresponding box to edit the parameter information.



See Appendix A at the back of this manual for parameter descriptions.




NOTE: Tap **Find Battery** to search for the battery location based on the vehicle year, make, and model based on the VIN or vehicle year, make, and model selected.



NOTE: Tap **Reset** to re-enter the battery rating if a replacement battery has been selected.


8. Align the temperature sensor on the Controller over the battery and tap **Capture**. The Battery Test begins when the temperature is successfully captured.



System Test

1. When prompted, start the engine and let it idle.
2. Tap **Next**. The analyzer tests the alternator output.
3. When prompted, rev the engine to between 2000 to 3000 rpm and tap **Next**.
4. Hold the engine revs while the analyzer tests the alternator output again.
5. When prompted, idle the engine.
6. When prompted, turn on the vehicle's high beam headlights and the interior blower fan.
7. When prompted, rev the engine to between 2000 to 3000 rpm and tap **Next**.
8. Hold the engine revs while the analyzer tests the alternator output again.
9. When prompted Idle the engine and then turn it off.
10. Tap **Next** to display the test results.

Test Results-Summary






Test Results - Summary

A Test Results-Summary screen is displayed following a System Test. Tap > to view detailed test results for each part of the test.

To send the test results to a configured printer or via email tap **Send Results**. To return to the Home Screen, tap **Done** or to return to the Main Menu.

Battery Test Results






The test results are displayed on the Controller screen.






Test Results - Battery Test

1. To send the test results to a configured printer or email address, tap **Send Results**.
2. Tap **Email** to send the results via email or **Print** to print the results using a configured printer.
3. Tap **Done** or to return to the Main Menu.



Test Results - Battery Test

Decision	Cranking Health	Reserve Capacity	Description
 Good Battery	Good Battery	Good Battery	Battery meets or exceeds required standards.
	Good Battery	Unknown Reserve	Battery meets or exceeds required standards.
	Good Recharge	Good Battery	Battery is good, but low on charge. Fully charge the battery for optimal performance and life. Check for causes of low charge.
Charge & Retest	Good Battery		
 Good Recharge	Good Recharge	Unknown Reserve	
	Charge & Retest	Unknown Reserve	
 Charge & Retest	Charge & Retest	Unknown Reserve	Battery requires charge to determine condition.
	Badcell Replace Short	Replace Battery	Battery fails to meet industry accepted standards.
 Replace Battery	Charge & Retest	Replace Battery	Battery is low in charge and shows low reserve capacity. Low reserve capacity will compromise the battery's ability to provide system current and hold a charge.
	Good Battery	Replace Battery	Battery fails to meet industry accepted standards
	Good Recharge	Replace Battery	
	Replace Battery	Good Battery	
	Replace Battery	Replace Battery	
Replace Battery	Unknown Reserve		
 Badcell Short Replace	Badcell Replace Short	Good Battery	
	Badcell Replace Short	Unknown Reserve	

Test Results - Reserve Capacity







Decision	Action
 OK	The battery has sufficient reserve capacity to provide power for the electronics systems in the vehicle.
 Warning	The battery reserve capacity is low, which can impact power for vehicle electronics including console screen, entertainment systems, power seats, etc... Recommend replacing the battery.
 No Test	System conditions have prevented a testing battery reserve capacity. Ensure all vehicle accessory loads are off, the key is not in the ignition, and the doors are close. Then test again.

Starter Test Results





Test Results - Starter Test

Test Results - Starter

Decision	Action
 Cranking Normal	The starter voltage is normal and the battery is fully charged.
 Low Voltage	The starter voltage is low and the battery is fully charged.
 Charge Battery	The starter voltage is low and the battery is discharged. Fully charge the battery and repeat the starter system test.
 Replace Battery	(If the battery test result was (REPLACE or BAD CELL.) The battery must be replaced before testing the starter.
 Low Current	The starter voltage is high but the cranking amps are low.
 No Start	The engine didn't start and the test was aborted or the vehicle's starting profile was not detected and the Starter Test was skipped.

Alternator Test Results



Test Results - Alternator Test

Test Results - Alternator

Decision	Action
Charging Normal	The output from the alternator is normal.
No Output	No output detected. Check belts to ensure alternator is rotating when engine is running. ✓ Check all alternator connections including to the battery. Clean or replace if necessary and retest. ✓ If the belts and connections are in good working condition, replace alternator or external voltage regulator.
Low Output	Alternator not providing enough current to power electrical loads and charge the battery. ✓ Check belts to ensure the alternator is rotating with the engine running. ✓ Check alternator connections to and from the battery. If loose or heavily corroded, clean or replace the cable and retest.
High Output	Alternator voltage to the battery exceeds normal limits of a functioning regulator. ✓ Check for loose and normal ground connections. If no connection problems are found, replace the regulator. The normal high limit of a typical automotive regulator is 14.5 volts +/-0.5. Refer to the manufacturer specifications for the correct limit, which may vary by vehicle type.

Test Results - Diode

Decision	Action
Excessive Ripple	One or more diodes in the alternator are not functioning or there is stator damage, which is shown by an excessive amount of AC ripple current supplied to the battery. ✓ Make sure the alternator mounting is sturdy and that the belts are in good shape and functioning properly. If the mounting and belts are good, replace the alternator.
Open Phase	Replace the alternator.
Open Diode	
Shorted Diode	

Chapter 3: Battery Test




Use Battery Test to perform tests on vehicles brought in for service using test parameters determined by VIN of the vehicle being tested.

At any time during the test tap to return to the previous screen or to return to the Main Menu.

1. Connect the Tester Pod test clamps to the battery (**Black** to negative [-], **Red** to [+]).
2. Press the Controller Release Lever and disconnect the Controller from the Tester Pod.
3. On the Controller at the Main Menu tap the **Battery Test** icon.
4. Tap **Next** at the Connect Clamps screen. The Acquire VIN screen is displayed.
5. Use the camera built into the back of the Controller handle to scan the VIN bar code. For best results, use the barcode located on the driver's side door frame. The VIN is also displayed behind the windshield on the driver's side dashboard.



NOTE: Refer to Appendix B for recommended scanning procedures and VIN scanning help.




Controller



Drivers Door Frame



Windshield



Manual Entry: Use the on-screen keypad to manually type the 17-digit VIN and tap **Next**.

1	2	3	4	5	6	7	8	9	0
W	E	R	T	Y	U	P			
A	S	D	F	G	H	J	K	L	
Z	X	C	V	B	N	M			
Back									Next


The displayed digit counter will count up the alphanumeric characters as they are being entered on the keypad.

6. If this is the first time the vehicle is being tested tap **Yes** if the installed battery is original equipment or **No** a replacement battery has been installed.

If **No** is selected, enter the battery rating. Tap Reset to re-enter the battery rating

7. The Edit Battery Information screen displays vehicle and battery information based on the VIN.

If the displayed information is correct, tap **Next** to begin the Battery Test. Tap on the corresponding box to edit the parameter information.



See Appendix A at the back of this manual for parameter descriptions.




NOTE: Tap **Find Battery** to display a battery location diagram for the vehicle being tested (based on the captured VIN).






NOTE: Tap **Reset** to re-enter the battery rating if a replacement battery has been selected.

- Align the temperature sensor on the Controller over the battery and tap **Capture**. The test begins when the temperature is successfully captured.



- To send the test results to a configured printer or email address, tap **Send Results**.
- Tap **Email** to send the results via email or Print to print the results using a configured printer.
- Tap **Done** or **Home** to return to the Main Menu.

The test results are displayed on the Controller screen.




Test Results - Battery Test



NOTE: See System Test Results in Chapter 2: System Test for a full explanation of all possible test outcomes.

Chapter 4: Check In




Use Check In for preliminary battery testing of newly arrived vehicles to ensure it will not sit in a low state of charge for an extended period of time potentially damaging the battery. Renders “Good Battery” or “Charge and Retest” decisions based on measured battery voltage.

At any time during the test tap ◀ to return to the previous screen or 🏠 to return to the Main Menu.

1. Connect the Tester Pod test clamps to the battery (**Black** to negative [-], **Red** to [+]).
2. Press the Controller Release Lever and disconnect the Controller from the Tester Pod.
3. On the Controller at the Main Menu tap the **Check In** icon.
4. Tap **Next** at the Connect Clamps screen. The Acquire VIN screen is displayed.
5. Use the camera built into the back of the Controller handle to scan the VIN bar code. For best results, use the barcode located on the driver’s side door frame. The VIN is also displayed behind the windshield on the driver’s side dashboard.



NOTE: Refer to Appendix B for recommended scanning procedures and VIN scanning help.




Controller




Drivers Door Frame



Windshield




Manual Entry: Use the on-screen keypad to manually type the 17-digit VIN and tap **Next**.



The displayed digit counter will count up the alphanumeric characters as they are being entered on the keypad.

6. The Edit Battery Information screen displays vehicle and battery information based on the VIN.

If the displayed information is correct, tap **Next** to begin the Battery Test. Tap on the corresponding box to edit the parameter information.



See Appendix A at the back of this manual for parameter descriptions.




NOTE: Tap **Find Battery** to display a battery location diagram for the vehicle being tested (based on the captured VIN).




NOTE: Tap **Reset** to re-enter the battery rating if a replacement battery has been selected.

- Align the temperature sensor on the Controller over the battery and tap **Capture**. The test begins when the temperature is successfully captured.



The test results are displayed on the Controller screen.




Test Results - Battery Test



NOTE: See System Test Results in Chapter 2: System Test for a full explanation of all possible test outcomes.

- To send the test results to a configured printer or email address, tap **Send Results**.
- Tap **Email** to send the results via email or **Print** to print the results using a configured printer.
- Tap **Done** or **Home** to return to the Main Menu.

Chapter 5: Customer Delivery




Use Customer Delivery to perform a battery test right before a vehicle is delivered to a customer to ensure a bad battery is not delivered to the customer potentially resulting in a return visit. Renders “Good Battery” or “Charge and Retest” decisions based on measured battery voltage.

Tap to return to the previous screen or to return to the Main Menu.

1. Connect the Tester Pod test clamps to the battery (**Black** to negative [-], **Red** to [+]).
2. Press the Controller Release Lever and disconnect the Controller from the Tester Pod.
3. On the Controller at the Main Menu tap the **Customer Delivery** icon.
4. Tap **Next** at the Connect Clamps screen. The Acquire VIN screen is displayed.
5. Use the camera built into the back of the Controller handle to scan the VIN bar code. For best results, use the barcode located on the driver’s side door frame. The VIN is also displayed behind the windshield on the driver’s side dashboard.



NOTE: Refer to Appendix B for recommended scanning procedures and VIN scanning help.




Controller



Drivers Door Frame



Windshield




Manual Entry: Use the on-screen keypad to manually type the 17-digit VIN and tap **Next**.

1	2	3	4	5	6	7	8	9	0
W	E	R	T	Y	U	P			
A	S	D	F	G	H	J	K	L	
Z	X	C	V	B	N	M			
Back									Next

The displayed digit counter will count up the alphanumeric characters as they are being entered on the keypad.

6. The Edit Battery Information screen displays vehicle and battery information based on the VIN.

If the displayed information is correct, tap **Next** to begin the Battery Test. Tap on the corresponding box to edit the parameter information.



See Appendix A at the back of this manual for parameter descriptions.




NOTE: Tap **Find Battery** to display a battery location diagram for the vehicle being tested (based on the captured VIN).




NOTE: Tap **Reset** to re-enter the battery rating if a replacement battery has been selected.

- Align the temperature sensor on the Controller over the battery and tap **Capture**. The test begins when the temperature is successfully captured.



The test results are displayed on the Controller screen.




Test Results - Battery Test



NOTE: See System Test Results in Chapter 2: System Test for a full explanation of all possible test outcomes.

- To send the test results to a configured printer or email address, tap **Send Results**.
- Tap **Email** to send the results via email or **Print** to print the results using a configured printer.
- Tap **Done** or **Home** to return to the Main Menu.

Chapter 6: Inventory




Use Inventory to perform a battery test on a vehicle that has been sitting on a lot, port, or any other extended time waiting to be delivered or sold. This will identify batteries needing charging, keep inventory batteries healthy and reduce bad customer service experiences..

Tap to return to the previous screen or to return to the Main Menu.

1. Connect the Tester Pod test clamps to the battery (**Black** to negative [-], **Red** to [+]).
2. Press the Controller Release Lever and disconnect the Controller from the Tester Pod.
3. On the Controller at the Main Menu tap the **Inventory** icon.
4. Tap **Next** at the Connect Clamps screen. The Acquire VIN screen is displayed.
5. Use the camera built into the back of the Controller handle to scan the VIN bar code. For best results, use the barcode located on the driver's side door frame. The VIN is also displayed behind the windshield on the driver's side dashboard.



NOTE: Refer to Appendix B for recommended scanning procedures and VIN scanning help.




Controller




Drivers Door Frame



Windshield




Manual Entry: Use the on-screen keypad to manually type the 17-digit VIN and tap **Next**.



The displayed digit counter will count up the alphanumeric characters as they are being entered on the keypad.

6. The Edit Battery Information screen displays vehicle and battery information based on the VIN.

If the displayed information is correct, tap **Next** to begin the Battery Test. Tap on the corresponding box to edit the parameter information.



See Appendix A at the back of this manual for parameter descriptions.




NOTE: Tap **Find Battery** to display a battery location diagram for the vehicle being tested (based on the captured VIN).



NOTE: Tap **Reset** to re-enter the battery rating if a replacement battery has been selected.


- Align the temperature sensor on the Controller over the battery and tap **Capture**. The test begins when the temperature is successfully captured.



The test results are displayed on the Controller screen.



NOTE: A warning screen is displayed if the battery requires charging or replacing.




Test Results - Battery Test



NOTE: See System Test Results in Chapter 2: System Test for a full explanation of all possible test outcomes.

- To send the test results to a configured printer or email address, tap **Send Results**.
- Tap **Email** to send the results via email or **Print** to print the results using a configured printer.
- Tap **Done** or **Home** to return to the Main Menu.

Chapter 7: Messages



The Messages function displays alerts and notifications for upcoming tests and activities. This includes scheduled testing as well as tool software updates and maintenance opportunities.



Mark Read Or Unread



Delete Notification





Perform Message Action

Tap ◀ to return to the previous screen or 🏠 to return to the Main Menu.


Accessing Messages






A number is displayed next to the Messages icon when the analyzer has received any critical messages. The number does not include non-critical Notifications.

-  Unread Critical Messages
-  Read Critical Messages

1. Tap **Messages** on the Main Menu screen.




2. Tap  to read a message.
Tap  to perform the message action item.
Tap  to delete a message.
3. Tap ^ to collapse a list of messages or v to expand the list.

Message Types

Critical: An important action cannot be performed and may require user action.


Notifications: Indicates an action has been performed or data has been sent.

Chapter 8: History



Use History to access the tool usage history, a vehicle history based on VIN, and user histories. The search function can also be used find test records for specific vehicles and technicians.

At the Main Menu, tap **History**. By default the Tool History screen is displayed.



Tool History



Use Tool History to view test total history as well as in vehicle and out of vehicle test totals. Individual test results are also displayed.

Tap > to view individual test details.

Tap ∑ to view Total By Test Decision, Total By Test Type, and Total By Date And Location.

Tap **Done** to return to the Tool History screen.

Totals By Test Decision

The totals are displayed by possible results for all battery chemistries and potential test results.

Good Battery	BC Open Or Load Fail Replace
Good Recharge	Broken Weld Replace
Charge & Retest	Temp Sensor Failed
Replace Battery	Aborted
Badcell Short Replace	Invalid Test
Remote Post	Aborted / 24V
Side Post	Out Of Balance

Totals By Test Type

Displays test totals by test type.

System Test	Customer Delivery
Battery Test	Inventory
Check In	

Totals By Date And Location

Displays test totals by time interval. Also displays the number of tests performed in and out of vehicle.

Last 7 Days	In Vehicle
Last 30 Days	Out Vehicle
Last 90 Days	

Vehicle History



Vehicle History displays test totals conducted on specific vehicles based on the VIN. It is also possible to enter a VIN to search for test records for a specific vehicle by tapping the displayed buttons.


Tap on the records displayed on the right side of the screen to view the individual test results.

Vehicle Select Option

Tap **Q** to select vehicle search option.

Manual Lookup: Use the on-screen keypad to manually type the 17-digit VIN and tap **Next**.

VIN Scan: Use the camera built into the back of the Controller handle to scan the VIN bar code. For best results, use the barcode located on the driver's side door frame. The VIN is also displayed behind the windshield on the driver's side dashboard.



Controller



Drivers Door Frame



Windshield

Search: Search records by Vehicle Year, Make, and Model.

User History



User History displays test totals for the user that is currently logged in to the analyzer.

Tap > to view individual test details.

Tap ∑ to view Total By Test Decision, Total By Test Type, and Total By Date And Location.

Chapter 9: Settings



Settings

Use the Settings options to setup and adjust WiFi, printer setup and selection, email settings, user information, default language, display settings, sound settings, BMIS login information, shop information, user management, connected accessories, and device information.

Tap ◀ to return to the previous screen or 🏠 to return to the Main Menu.

WiFi



Use WiFi to view, add, and delete wireless networks.

Tap on the WiFi icon to display a list of detected and configured WiFi networks.



Add Network



Delete Selected Network




Connect Highlighted Network



Refresh Network List


WiFi Setup Procedure

1. At the Main Menu, tap Settings.
2. Tap on the WiFi icon  to display a list of configured WiFi networks.




NOTE: If initial setup is being performed, the network add list is displayed by default as there are no configured networks. See Adding A Network.



If a network has been previously configured, the DSS-5000 will automatically connect. An (X) will appear over the network signal strength indicator if the network is not within range or available.

3. If more than one network has been configured, the active network is displayed first in the list. To select a different network, tap the network name then tap .

When connected, the network name moves to the top of the list with ● displayed next to it. An error message is displayed if the DSS-5000 was not able to connect to the selected network.

4. Tap X to exit and return to the network list.
5. Tap  to return to the Main Menu.

Adding A Network

1. Tap  to add a WiFi network.
A list of detected WiFi networks is displayed.
2. To add a network manually tap  again. Network SSID, Security and IP Settings are required fields.
3. Tap the network name from the list of detected WiFi networks to access the Security and IP Settings. A password may also be required (may require IT assistance).

Security	None WEP WPA/WPA2 PSK
IP Address	DHCP Static




NOTE: Passwords can be case-sensitive. Make note of passwords and the on-screen keypad to avoid connection failures due to incorrect password entry.


4. Tap → to configure the selected network.



NOTE: If the selected network requires a User Authentication page, the message “Sign in to WiFi network” is displayed. Tap Continue to be redirected to the page. User credentials (ex. User Name and Password) may require IT assistance.

5. Once the network has been successfully configured, tap → to return to the list of available configured networks. The selected network is displayed at the top of the list with a ● next to it.
6. Tap  to return to the Main Menu.

Deleting A Network

1. Tap a displayed network.
2. Tap  to delete the network and tap Yes to confirm.

Printer Settings




The Printer Setup function detects and displays a list of connected and available WiFi and Bluetooth printers.



NOTE: WiFi network communication must be successfully established before a printer or printers can be detected and setup.

Tap on the Printer icon to display a list of available printers on the configured WiFi and Bluetooth networks.



Adding A WiFi Printer (Admin Only)

1. Tap to access the Printer Setup functions.
2. Tap to add a WiFi printer.
Make sure the printer is on and connected to the same wireless network as the analyzer.
3. Tap to add the printer to the list of eligible printers.
4. Tap to connect to the selected printer. A message is displayed when the configuration is successful.
5. Tap to return to the printer list.

Adding A Bluetooth Printer (Admin Only)

1. Tap the sign to add a Bluetooth printer.
2. Make sure the printer(s) is on.
3. Tap to add the printer to the list of eligible printers.
4. Tap to connect to the selected printer.
5. When prompted, enter the device PIN and tap . A message is displayed when the pairing is successful.
6. Tap to return to the printer list.


Deleting A Printer (Admin Only)

1. Tap to access the Printer Setup functions.
2. Tap a displayed printer.
3. Tap to delete the printer and tap Yes to confirm.

Email



Displays all entered email addresses. Addresses can be added, edited, and deleted (Admin Only). Entered email accounts are added to the email address book. Frequently used email addresses can be selected from the displayed address list rather than being re-typed each time.



Add Address (Admin Only)

1. Tap to add an email address.
2. Use the displayed keypad to enter the contact name and email address.
3. Tap Add to add the address to the email list or Cancel to exit and return to the email list.

Edit Address (Admin Only)

1. Select a displayed email address by tapping it.
2. Tap to edit the address.
3. Use the displayed keypad to edit the contact name and email address.
4. Tap Add to add the address to the email list or Cancel to exit and return to the email list.

Deleting An Address (Admin Only)

1. Select the email address by tapping it.
2. Tap to delete the address and tap Yes to confirm or Cancel to exit and return to the email list.

Server Settings

Enter and edit the email settings for sending outgoing email.

1. Tap to access the email sever settings.
2. Tap to enter or modify existing server settings including Host, Port, Login, Password, SMTP Authorization, Enable TLS, and From Email Address information.
3. Tap to clear all server settings.
4. Tap to return to the email Address Book.

User Settings (Admin Only)



Modify Usernames and Passwords..



Edit Users



User Settings







Delete Users



User Management

User Management (Admin Only)

1. Tap  to access User Management functions.
1. Tap  to display the current logged in Admin user.
2. Select a displayed user by tapping it.
3. Tap  to edit the Username, Password, and User Type (Standard or Admin).
4. Tap **X** when complete to return to the User Management screen.
5. Tap  to delete the selected user and Yes to confirm.

Language Settings



Use the Language & Input function to select the default system language used by the tool. User defaults also include Test Results, Email, and Print languages.

System Language

Select the default standard language for the analyzer to use on the Controller.

Test Result Language

Select the default language for the analyzer to use for all tests and results displayed on the Controller.

Email Language

Select the default standard language for the analyzer to use for all tests and results sent via email.

Print Language

Select the default standard language for the analyzer to use for all tests and results printed using a networked printer.

Display Settings



Adjust the Controller display including the Brightness, Sleep Time, and Dim Time. Auto Brightness can also be turned on and off.

Brightness

Adjust the display Brightness by tapping and holding the slider, then moving it right or left to make the screen brighter or darker.

Auto Brightness

Enable and disable Auto Brightness by tapping on the check box.

Sleep Time

Adjust the amount of elapsed time before the Controller goes into a power saving (Sleep) mode. Default = 2 minutes.

Dim Time

Adjust the amount of elapsed time before the Controller goes into a power saving (Dim) mode. Default = 1 minute.

BMIS Login (Admin Only)




Enter and edit BMIS Login and Password information. Log into a BMIS account.

Login

Password

Shop Information (Admin Only)

 Access default Shop Information including Store Name, address, and phone number. Also access battery test defaults including rating, temperature units, and decimal separator. Use also to adjust the tester date and time settings.


	Settings Home		Date/Time Settings
	Test Settings		Create MDCA Log File


Shop Information

Use the onscreen keypad to enter the store name, address, and phone number.

Store Name	<input type="text" value="Midtronics"/>
Street Address	<input type="text" value="7000 Monroe"/>
Street Address 2	<input type="text"/>
City	<input type="text" value="Willowbrook"/>
State	<input type="text" value="IL"/>
Zipcode	<input type="text" value="60527"/>
Phone #	<input type="text" value="1-630-323-2800"/>

Test Settings

1. Tap  to access the test setting defaults. Tap the boxes or icons to change the values.

Battery Rating	<input type="text" value="CCA"/>
Temperature Units	<input type="text" value="°F"/>
Decimal Separator	<input type="text" value="00.00"/>
Create MDCA Log File	

Battery Rating

Default battery rating units used when testing batteries.

Temperature Units

Default temperature units used when measuring battery temperature.

Decimal Separator

Default number display using commas or periods separators.



Create MDCA Log File

The MDCA function is used by Midtronics technical support to assist in troubleshooting. Only generate this file when directed to do so by Midtronics technical support.

2. Tap  to return to the Shop Information screen.

Date/Time Settings

1. Tap  to access the Date/Time setting defaults.

Select Time Format	<input type="text" value="12 Hour"/>
Select Date Format	<input type="text" value="10/18/2016"/>
Select Time Zone	<input type="text" value="EST"/>
Set Date	
Set Time	

Select Time Format

12 or 24 Hour Format



Select Date Format







Month/Day/Year, Day/Month/Year, or Year/Day/Month

Select Time Zone



Time zone in which the analyzer will be operated.







Set Date

Tap  or  to enter the month, day, and year. Tap Set to save the date or Cancel to exit without saving.

		
Apr	17	2017
May	18	2017
Jun	19	2017
		
CANCEL		SET

Set Time

Tap  or  to enter the hours, minutes, and AM/PM. Tap Set to save the date or Cancel to exit without saving.

		
9	50	AM
10	51	PM
11	52	
		
CANCEL		SET

2. Tap  to return to the Shop Information screen.

Device List



Displays connected and linked accessory devices. Additional devices and CVG-2 modules can also be detected and linked to the analyzer.



Add



Refresh







Delete Paired Device



Enabled

Add Tester Pod

1. Tap  to add a device.
2. Move the device to be linked within 30 feet of the Controller, turn on the device, then tap .
3. A list of detected devices is displayed. Tap  next to the desired device to select it. If the desired device is not displayed, tap  to refresh the list.




NOTE: A passkey number is automatically generated once the Bluetooth pairing has been established.




A confirmation message is displayed when the device has been successfully linked.

4. Tap  to return to the Device List screen.

Deleting A Diagnostic Base

1. Tap  next to the base to be deleted.
2. Tap Yes to delete.

Add CVG Device

1. Tap  to add a CVG.
2. Plug the CVG into the OBDII port of any vehicle.
3. Turn the vehicle ignition on, but do not start the vehicle.
4. A list of detected CVGs is displayed. Tap  next to the desired CVG to select it. If the desired CVG is not displayed, tap  to refresh the list.



NOTE: A passkey number is automatically generated once the Bluetooth pairing has been established.

A confirmation message is displayed when the CVG has been successfully linked.

5. Tap  to return to the Device List screen.

Version Information



Use Version Information to display WiFi connection data the DSS Controller, Diagnostic Device, and CVG-2 Device software version information.



Factory Reset



Check For Updates



Legal Information

DSS Serial Number

WiFi MAC Address

Configuration Version

Data Version

DSS Controller Version

Diagnostic Device Version

CVG-2 Device Version

No Device Configured

OS Version

Factory Preset

Use this function to return the tool to the original as built configuration including all history and test settings.



IMPORTANT: All previous modifications to the original settings will be overwritten.


Legal Information

Displays software attribution information via the Midtronics website. The analyzer must be connected to the Internet.

Check for Updates

Use this function to check via the internet connection for any updates to the tester software.

Chapter 10: Support



Use the Support function to access built-in Self-Testing functions or to view a digitized version of the Instruction Manual.

User Manual




Tap the icon to view the analyzer's Instruction Manual.

Self-Diagnostics



Use to test WiFi network and printer connections, CVG pairing, Tester Pod diagnostics, Controller display testing, and Controller touch panel testing.



WiFi Self-Diagnostics	Tests connectivity to the BMIS server via the selected WiFi network
WiFi Printer Self-Diagnostics	Use to configure a WiFi printer
CVG Self-Diagnostics	Check connectivity to a configured CVG device
Tester Pod Self-Diagnostics	Check connectivity between the Controller and the Tester Pod
Display Self-Diagnostics	Tests Controller pixel display
Touchscreen Self-Diagnostics	Tests Controller touchscreen responsiveness

Appendix A: Battery Information Screen Descriptions

Stock Number	Dealer-assigned inventory tracking number.	
Color	Color of vehicle in inventory being tested.	
VIN	A unique code, including a serial number, used by the automotive industry to identify individual motor vehicles, motorcycles, scooters and mopeds, as defined in ISO 3833.	
Vehicle Year	Model year that a vehicle was manufactured.	
Vehicle Make	Vehicle manufacturer	
Vehicle Model	Vehicle name or number	
Vehicle Technology	Hybrid, Gasoline, Electric, Start-Stop, Hybrid Start-Stop, Diesel	
Battery Installation	Single Battery or Dual Batteries	
Battery Application	Automotive, Marine, Powersport, Group 31, Commercial 4D/8D, Lawn and Garden	
Battery Post	Top Post, Side Post, Dual Post	
Test Location	Top Post, Side Post, Remote Post	
Battery Type	Flooded, AGM (Absorbed Gas Mat), AGM Spiral, Gel, Enhanced Flooded	
Battery Units	CCA	Cold Cranking Amps: Battery current at 0 °F (-17.8 °C). 100 to 3000
	CA	Cranking Amps: Battery current at 32 °F (0 °C). 100 to 3000
	JIS	Japanese Industrial Standard: Usually printed on battery label. 26A17 to 245H52
	DIN(A)	Deutsche Industrie-Norm 100 to 1000
	SAE(A)	European labeling of CCA 100 to 3000
	IEC(A)	International Electrotechnical Commission 100 to 1000
	EN(A)	Europa-Norm 100 to 1700
	EN2(A)	Europa-Norm 100 to 1700
Battery Rating	Enter the Battery Rating Units value.	

Appendix B: Recommended Test Procedure

The DSS-5000 testing process uses Conductance Profiling™ technology which determines battery cranking capability and also adds Reserve Capacity testing. With this additional process, initial battery analysis can take up to 60 seconds to complete.



IMPORTANT: Always begin each test by connecting the Tester Pod clamps to the battery being tested. The testing process begins as soon as the clamps are connected.


The DSS-5000 provides a battery decision along with additional detailed information on battery cranking and reserve capacity. Swipe the screen horizontally to the right or left to view the additional results screens. (See Page 3)

VIN Scanning

The DSS-5000 uses a camera built into the Controller handle to scan the VIN of the vehicle being tested. This number is then cross referenced with the original equipment manufacturer's battery specifications stored in the tester's database and displayed on the Controller screen.

Scanning Tips

- **Camera:** Located in the upper left portion on the back of the Controller handle.



Controller




Drivers Door Frame



Windshield

- **Hold Steady:** Hold Controller steady when scanning the VIN barcode. This allows the user to clearly see the barcode and allows the camera to focus on it.



- **Fill Viewfinder:** Make sure the entire barcode is visible. Keeping the entire VIN barcode visible while slowly moving the camera closer or further away will help capture.
- **Clean Barcode/Windshield:** Surface dirt can interfere with the scanning process. If necessary wipe the VIN barcode with a cloth or your finger remove any surface dirt.
- **Lighting/Glare:** The built-in flashlight will automatically turn on in low light situations. If the flashlight, or sunlight, is shining directly onto the VIN barcode, try pivoting the camera up or down slightly to reduce any glare.

PATENTS

This product is made by Midtronics, Inc., and is protected by one or more U.S. and foreign patents. For specific patent information, contact Midtronics, Inc. at +1 630 323-2800.

LIMITED WARRANTY

The DSS-5000P NI and DSS-5000P INF products are warranted to be free of defects in materials and workmanship for a period of two (2) years on the analyzer and one (1) year on the test cables from date of purchase. Midtronics will, at our option, repair or replace the unit with a re-manufactured unit. This limited warranty applies only to Midtronics products, and does not cover any other equipment, static damage, water damage, overvoltage damage, dropping the unit, or damage resulting from extraneous causes including owner misuse. Midtronics is not liable for any incidental or consequential damages for breach of this warranty. The warranty is void if owner attempts to disassemble the unit or to modify the cable assembly.

SERVICE

To obtain service, contact Midtronics at 866-592-8052. Have your model and serial numbers ready. This first step is critical as we will trouble-shoot the problem(s) over the phone, and many problems are resolved during this step. If the problem cannot be resolved, then the Customer Service Agent will issue you a Return Material Authorization (RMA). This number becomes your tracking number. The final step is to return the unit to Midtronics freight prepaid (you pay), to the attention of the RMA number obtained.

In USA:

Midtronics, Inc.
Attn: RMA # xxxxx (this is the RMA number that you must obtain from Midtronics)
7000 Monroe St.
Willowbrook, IL 60527

In Canada:

Midtronics c/o FTN (FTN is Fed-ex Trade Networks –this is NOT a Midtronics facility)
Attn: RMA # xxxxx (this is the RMA number that you must obtain from Midtronics)
7075 Ordan Drive
Mississauga, ON L5T1K6

Midtronics will service and return the unit using the same type of service as received. If Midtronics determines that the failure was caused by misuse, alteration, accident, or abnormal condition of operation or handling, purchaser will be billed for the repaired product and it will be returned freight prepaid with shipping & handling charges added to the invoice. Midtronics products beyond the warranty period are subject to the repair charges in place at that time. Optional re-manufacturing service is available to return our products to like-new condition. Out-of-warranty repairs carry a 3-month warranty. Re-manufactured units purchased from Midtronics are covered by a 6-month warranty.



www.midtronics.com

Corporate Headquarters

Willowbrook, IL USA
Phone: 1.630.323.2800
Canadian Inquiries
Toll Free: +1 1 866 592 8052

Midtronics b.v.

European Headquarters
Houten, The Netherlands
Serving Europe, Africa, the Middle
East, and The Netherlands
Phone: +31 306 868 150

Midtronics China

China Operations
Shenzhen, China
Phone: +86 755 2374 1010

Midtronics India

Navi Mumbai, India
Phone: +91 22 2756 4103/1513
Asia/Pacific (excluding China)
Contact Corporate Headquarters
Phone: +1.630.323.2800