



Special Tool Storage System

Master Index - Part Number Order (Non-illustrated)



TECH·MATE

**NISSAN AUTHORIZED
TOOL & EQUIPMENT PROGRAM**

1-800-662-2001 • nissantechmate.com

TECH·MATE

**INFINITI AUTHORIZED
TOOL & EQUIPMENT PROGRAM**

1-800-662-2001 • infinititechmate.com



Special Tool Storage System



Tool Number	Description	N	I	Drawer
1-20-2722-1	Wheel Clamp	*	*	Shop
1-20-2851-1	ICC/FCW Sensor Alignment Target	*	*	Shop
16-2002	Floor Crane (Leaf EV)	*		Shop
165-DSS-5000P-INF	Midtronics Battery Charger and Tester		*	Shop
165-DSS-5000P-NI	Midtronics Battery Charger and Tester	*		Shop
165-GR8-1200KIT-INF	Cart Based Battery Tester & Charger		*	Shop
165-GR8-1200KIT-NI	Cart Based Battery Tester & Charger	*		Shop
1699200115	MTS 6513 Repro Tool	*		5
1-ACE-INF	Auto Comp Elite Lathe		*	Shop
1-ACE-NIS	Auto Comp Elite Lathe	*		Shop
204-BX50W-NI	LiB Lift Table (Leaf EV)	*		Shop
204-ST65H-NI	LiB Pallet Stacker (Leaf EV)	*		Shop
223-97202	Wireless Chassis Ear	*	*	Shop
38-50-6ADP	Pro-Cut 6 Adapter Package	*	*	Shop
38-50-ACC	Pro-Cut Accessory Package	*	*	Shop
38-92-BASE-IBT	Pro-Cut 9.2 Lathe w/four post trolley. Package.	*	*	Shop
42-18465	Manual PAG Oil Dye Injector	*		10
42-LD 020	Dual Mode Refrigerant Leak Detector	*		24
425-C9100020	Key Cutter	*		Shop
48710	A/C Service Machine	*	*	Shop
551243	Cable, Varistor Check Tool Repl.	*	*	11
697-95-0130-INF	Dual Pressure Diagnostic Leak Detector		*	Shop
697-95-0130-NIS	Dual Pressure Diagnostic Leak Detector	*		Shop
BT-8653-A	Torque Angle Gauge	*	*	13
J-8092	Driver Handle	*		4
J-02619-5	Slide Hammer	*		13
J-23688	Cool & Batt. Test. #7584L	*	*	15
J-24385-C	Axle Housing Spreader			25

Tool Number	Description	N	I	Drawer
J-24460-92	Cooling System Adapter	*	*	15
J-25721-A	Slide Hammer	*		12
J-28431-6	Fluorescent Oil Dye 6-1 oz. Bottles	*	*	15
J-29545-6A	Fluorescent Cool. Dye/6-1/4 oz	*	*	15
J-37066	Front Seat Installer	*		4
J-37228	Seal Cutter	*	*	3
J-38365-NI	Wrench, Air Fuel Sensor	*	*	3
J-38873-A	Drive Plate Installer	*		1
J-39570	Chassis EAR	*	*	17
J-41425-NIS	Aluminum Tubing Repair Kit	*	*	17
J-41540	Homelink Trans. Tester	*	*	17
J-42059	Cig. Lighter Socket Remover	*	*	2
J-42578	Steering Wheel Puller Legs	*	*	1
J-42738	Front Output SHFT Seal Inst.	*		4
J-42909	EVAP Kit	*	*	9
J-43415	Cowl Rivet Remover	*		1
J-43897-18	Cleaner, 18 mm Oxy Sensor Thread	*	*	3
J-43926	Air Conditioning Dye Kit	*	*	17
J-44321-A	Test Kit, Fuel Pressure	*	*	17
J-44372	5-50 Lb. Pull Gauge	*		10
J-44626	Socket, 22 mm Offset	*	*	3
J-44716	Ring Gear Stopper	*	*	3
J-45356	Leak Check Adapter	*	*	15
J-45404	Tool, Alignment	*		1
J-45475-A	Transmission Dipstick		*	10
J-45476	Ring Gear Stopper	*		3
J-45488	Fuel Line Disconnect Tool	*	*	2
J-45542	Adapter, Transmission	*		2
J-45674	AT Line Pressure Adapter	*	*	2
J-45695-A	Coolant Refill Tool	*	*	15
J-45722	Lock Ring Tool, 130 mm	*	*	14
J-45737	Torx Plus Bit (TP50)	*		3



Special Tool Storage System



Tool Number	Description	N	I	Drawer
J-45741-A	Test Kit, ABS Wheel Sensor	*	*	11
J-45747	Wrench, Lock Ring (4.5")	*	*	14
J-45804	Strut Bracket Measuring Gauge	*	*	3
J-45816	E20 Torx Socket	*	*	15
J-46211	Wrench, Fuel Tank Lock Ring	*		14
J-46214	Wrench, Fuel Tank Lock Ring	*		14
J-46528	Drive Plate Location Guide	*		1
J-46531	Bit, TP55 Torx	*		3
J-46532	Brake Height Tool	*	*	1
J-46534	Panel Popper Tool Set	*	*	2
J-46535	Idler Pulley Relief Tool	*		12
J-46536	Lock Ring Wrench, Titan Fuel	*	*	14
J-46538	Flameless Heat Gun	*	*	1
J-47005	Seal Installer	*		4
J-47007	Brembo Brake Tool	*	*	16
J-47126	Net Hook Tool	*		1
J-47128	VQ Rear Main Seal Installer	*	*	4
J-47244	L/H CVT Seal Installer	*		4
J-47245	Ring Gear Stopper	*	*	3
J-47321	Adapter Set, Trans. Jack		*	6
J-47327	Screwdriver, Preset Torque	*		1
J-47329	Kit, Vacuum Gauge	*	*	6
J-47437	Powervalue Alignment Tool	*		10
J-47446-EV-DIAG	Security Card/Adapter (Leaf EV)	*		Shop
J-47446-GTR	GT-R Diagnostics Kit (GTR)	*		Shop
J-47447	Crank Pos'n Sensor Deburr Tool	*	*	1
J-48641	Ring Gear Stopper		*	3
J-48761	Ring Gear Stopper	*		3
J-48763	Left Side Seal Installer (HEV)	*		4
J-48764	Right Side Seal Installer (HEV)	*		4
J-48766	Input Oil Seal Installer (HEV)	*		4

Tool Number	Description	N	I	Drawer
J-48767	HEV Service Hose Kit	*	*	15
J-48817-E	Harness Repair Kit	*		Shop
J-48817-INF	Harness Repair Kit		*	Shop
J-48850-15MY	DVD, Update Navigation (Set Of 2 Discs)	*	*	11
J-48850-A	Kit, Navigational Reprogramming Adaptor	*	*	11
J-48851	Half Shft Adapter (HEV)	*		13
J-48891	Socket, 14 mm Spark Plug	*	*	3
J-48968	Inst./Rem., Suspension Bushing		*	4
J-49023	Brake Caliper Tool (GTR)	*		16
J-49029	Strut Rod Clamp	*		12
J-49062	Wrench, 11 mm 12-Point	*	*	10
J-49063	Wrench, 12 mm 6-Point	*	*	10
J-49277	Ring Gear Stop		*	3
J-49286	Pull And Drift Gauge Set	*		11
J-49360	Gasket Scraper (Plastic) (GTR)	*		2
J-49387	Seat Track Gauge	*	*	1
J-49749	Brake Booster Vacuum	*		6
J-49815	Installer, Rear Oil Seal	*		4
J-49829	Transmission Oil Fill Kit	*	*	Shop
J-49961	Torque Adapter, 19 mm		*	1
J-50023	Transmission Holding Fixture	*	*	Shop
J-50097-FUEL	Fuel Test Kit	*	*	Shop
J-50097-NONFUEL	Fluid Test Kit	*	*	Shop
J-50190	Tire Pressure Monitor Tester	*	*	9
J-50246	VQ Tensioner Shoe Installer	*		3
J-50249	LEAF LiB Tool Kit (Leaf EV) (Stored in J-50365)	*		Shop
J-50255-B	CVT Transmission Kit	*		17
J-50262	Transaxle Seal Installer (GTR)	*		4
J-50278	Torque Adapter	*		10
J-50283	NV Rear Axle Rebuild Kit	*		25
J-50288	Ring Gear Stopper	*		3



Special Tool Storage System



Tool Number	Description	N	I	Drawer
J-50364	Direct Injection Seal Install	*	*	2
J-50365	EV Mobile Tool Storage and Workbench (Leaf EV)	*		Shop
J-50366	Direct Injection Puller	*	*	2
J-50367	Transfer Case Seal Installer	*		4
J-50392	ACM Holding Pins (GTR)	*		2
J-50393	Installer, Seal	*		4
J-50394	Installer, Seal	*		4
J-50397	Squeak & Rattle Repair Kit	*	*	9
J-50747	Murano Side Seal Installer	*		4
J-50777	Versa Combi Reprogramming Fixture	*		17
J-50816	Manual Applicator, 2:1, 400ML	*	*	6
J-50817	Installer, Oil Pump Seal CVT3	*		4
J-50818	Installer, Oil Pump Seal CVT2	*		4
J-50835	Installer, Rivet Nut	*		6
J-50836	Ratchet Tie Down	*	*	6
J-50878	Drill Bit, 33/64"	*		6
J-50976	Exhaust Decay Tool	*		13
J-50991	Fuel Sensor Wrench	*	*	3
J-51093	ICC Sensor Adjustment Tool		*	9
J-51269	VK56 Oil Jet Jig	*	*	5
J-51289	Seat Track Gauge	*		2
J-51316	Oil Jet Installer		*	5
J-51338	T50 Pulley Wrench Kit (Juke)	*		16
J-51360	USB Extension, 10 ft.	*	*	11
J-51387	HEV Ring Gear Stop	*	*	3
J-51392	Fluke 115 Digital Multimeter		*	11
J-51393	Engine Support Fixture (Juke)	*		16
J-51513	DLC Breakout Box	*	*	11
J-51594	USB to DLC Cable	*	*	11
J-51595	CVT Lifter Bracket (Slinger)	*		6
J-51771	Smart Fit Radiator Pressure Test Kit	*	*	15

Tool Number	Description	N	I	Drawer
J-51782	Antenna Diagnostic Kit	*	*	17
J-51813	Fuel Sensor Socket, 27 mm	*	*	3
J-51863	Air Bag Spring Release Tool	*	*	2
J-51874	Trunk Torsion Spring Tool	*		2
J-51875	Evap. Port Kit	*	*	2
J-51879	Axle Repair Kit	*		25
J-51909	Lifting Fixture, CVT	*		6
J-51922	EMMIT Kit			Shop
J-51922-INF	EMMIT Kit			Shop
J-51924	Rear Crankshaft seal Installer		*	8
J-51925	Rear Ring Gear Stop		*	8
J-51926	Oil Pressure Test Cap		*	8
J-51927	Socket Wrench		*	8
J-51928	Injector Seal Installer		*	8
J-51929	Drift, Seal Installer, Rail		*	8
J-51930	Injector Puller		*	7
J-51931	Camshaft Holder		*	8
J-51933	Ring Gear Stop		*	7
J-51935	Assembly Lever		*	7
J-51936	Drift		*	7
J-51939	Puller		*	7
J-51940	Dipstick		*	7
J-51941	Assembly Tool		*	8
J-51942	Lifting Device		*	8
J-51943	Drift		*	8
J-51945	Seal Installer, Diff.		*	8
J-51946	Seal Installer, Diff., Front		*	8
J-51947	Thrust Washer M 10X1.5		*	7
J-51948	Socket Wrench Bit		*	7
J-51950	OCS Plates		*	Bulk Storage
J-51951	Bore Scope Kit, With 90 Degree Mirror	*	*	9



Special Tool Storage System



Tool Number	Description	N	I	Drawer
J-51956	Ring Gear Stop		*	7
J-51959	Guide Pin Set	*		2
J-51970	Output Seal Installer, AWD		*	8
J-51980	TPMS Valve Stem Installer/Removal Tool	*		5
J-51981	Transmission Jack Adapter	*		Bulk Storage
J-52038	Window Regulator Rivet Installer		*	16
J-52082	CVT Lifting Bracket	*		11
J-52173	Valeo AC Clutch Compressor Tool	*	*	5
J-52226	Ring Gage, Go/No-Go	*		1
J-52227	Gas Venting Jig	*		1
J-52231	Strut Prop. Rod	*		1
J-52233	Double Sided Velcro Fastener	*		1
J-52258	Airbag Socket Depth Gauge	*		3
J-52266	Alignment Targets (3/PKG)		*	Bulk Storage
J-52266-NIS	Alignment Targets (2/PKG)	*		Bulk Storage
J-52272	Assembly Guide Pins	*		3
J-52273	Clutch Engagement Tool	*		5
J-52275	Side Cover Alignment	*		24
J-52278	Input Seal Installer T/C side	*		4
J-52280	Seal Driver Handle, Short	*		4
J-52281	FK K2 Output Seal Installer (Case side)	*		4
J-52282	FK K2 Output Seal Installer (T/C side)	*		4
J-52283	FK*K2 Output Seal Installer (Case side)	*		4
J-52284	FK*K2 Output Seal Installer (T/C side)	*		4
J-52306	Transmission Range Switch (PNP), CVT	*		2
J-52352	2D Bar Code Scanner	*	*	11
J-52389	Engine Support Fixture	*		Shop
J-52390	Seal Installer	*		3

Tool Number	Description	N	I	Drawer
J-52391	Seal Installer	*		3
J-52392	Exhaust Gas Temperature Sensor Wrench		*	5
J-52405	R1234YF RRR Service Kit	*		Shop
J-52469	Seal Protector Kit - Set of Three	*	*	5
J-52470	Leaf Spring Clamp	*		10
J-52473	DX CVT Trans. Jack Adapter	*		Bulk Storage
J-52475	2.5L Engine Adapter	*		Bulk Storage
J-52504	Foam Spacer Alignment Tool	*		1
J-52505	Rear Differential Seal Installer		*	4
J-52508	Trans Range Adjuster		*	8
J-52521	Heads Up Display Target		*	Bulk Storage
J-52524	16mm Torque Adapter	*		1
J-52528	Injector Line Torque Adapter	*	*	5
J-52551	Airbag Release Tool	*		7
J-52553	Cam Cover Seal Installer		*	8
J-52560	Ring Gear Stop		*	7
J-54201	Kit, Consult III, Plus VI, W/SFTW	*	*	9
J-54400	Cummins Engine Tool Kit	*		Bulk Storage