

INSTRUCTIONS

NOTE: Replacement kit tool #J-50097-FUEL will be automatically shipped to you after your sample's lab results are processed.

For use by properly trained personnel. Complete training prior to shipment.



Visit <http://shipmateuniversity.com/mod/scorm/view.php?id=91>

Training Course login:

User Name: Dealer Code

Password: Dealership's 5 Digit Zip Code

Questions? Please contact Nissan TechMate: 800-662-2001 or email: oetech@service-solutions.com

Dealer Information

Customer Name _____

Technician Name _____

VIN _____

RO# _____ RO Date _____

Dealer Name _____

Dealer Code _____

Email Address #1 _____

Email Address #2 _____

Sample Information

GASOLINE ONLY - GASOLINE ONLY SAMPLE KIT. DO NOT SHIP ANY OTHER FLUID IN THIS KIT.

Fuel Sample Packing Instructions: Kit # J-50097-FUEL

Important: Please complete training prior to using this kit. See reverse side for information.



1. Carefully fill each fuel sample bottle. Use a funnel if necessary. Do not contaminate or the tests may be invalid. Fill each 30 ml bottle no more than 90% full. Note the "Max Fill" Line on the label. (Headspace allows for expansion of the fuel.)



2. Ensure that the cap is **closed firmly**. Hand-tight is sufficient. Do not use a wrench to tighten. Peel and Apply the sealing tape (provided) around the circumference of the cap. Wipe the outside of the bottle to ensure that it's free of residue.



3. Re-roll all three filled sample bottles back into the absorbent towel, place into the first plastic bag, and seal securely.



4. Re-insert into the second plastic bag, along with the second absorbent towel, and seal securely.



5. Place **upright** into the cardboard box. Complete the form on the reverse side of this sheet and place in the box.



6. Seal the box shut with the clear tape. Ensure that the pre-printed, pre-applied "E-label" (Excepted Quantities label) is not damaged or obscured in any way.

7. Deliver the package to a FedEx carrier only.

Program facilitated by:



BOSCH

**Automotive
Service Solutions**

655 Eisenhower Drive
Owatonna, MN 55060
Phone 800-662-2001
Fax 586-578-7375

565591 REV C